




WeMoke Driving Instructions

1. Access the key to the Moke via the lockbox. You will receive the code to the lockbox 15 minutes before your rental.
2. To start your Moke, pull out the RED button, located to the left of the steering column. Enter the key to the right of the steering column and turn it on. The gauge will show the charging level of the Moke.
3. Release the parking brake. Put your foot on the brake and push the gear shift to D (DRIVE).
4. To stop the Moke, gently press on the brake. Put the car in N (NEUTRAL) and engage the parking brake.
5. Turn off the Moke with the key. Push the RED button in. Return the key to the lockbox using the code you were sent. If the key is not replaced there will be a \$500 replacement charge.

General Instructions

1. Always pull out the RED button when you are turning on the Moke & push the RED button in when you are not driving.
2. Always engage the parking brake when you are not driving.
3. Always obey local and state laws. Never drive on highways or roads with higher speed limits than 35 MPH.
4. A fresh water rinse or wipe down is recommended when the Moke is exposed to salt air.
5. Always bring the charging cord with you and store it in the trunk.
6. Return the key to the lockbox using the code you were sent. If the key is not replaced there will be a \$500 replacement charge.



**PULL OUT THE BIG RED BUTTON BEFORE
YOU START THE MOKE**

Charging Instructions

1. Turn off the Moke, put it in neutral, engage parking brake and pull out the RED button, located to the left of the steering column.
2. ATTACH charging cord to the Moke. The charging port is located just above the front wheel on the driver's side, inside the fender well. To connect cord, first open port door, match shape guide/prongs and insert plug. Connect the cord's other side to standard US wall outlet (110).
3. Charge indicator lights will begin blinking green next to the plug-in port, and that means CHARGING is underway. Blinking lights indicate car is still charging, SOLID GREEN light = 100% charged. No light means the Moke is NOT charging.

Lockbox Instructions

You will receive your code to the lockbox 15 minutes prior to your reservation by text message. Once you are at your Moke, you will find the lockbox installed on the dashboard. Gently tap the middle of the lockbox until the lights come on. Once you see the numbers light up, enter the code you received and touch the unlock symbol next to the 0 on the lockbox. You will hear it unlock and pull down from the top to open the lockbox. Please remove the key and close the lockbox. It will automatically lock. Please repeat to replace the key when you return your Moke. Please make sure the lockbox is locked. If you do not replace the key at the end of your rental, there will be a \$500 charge for a lost key.

Thank you for MOKING with us!